

CrystalPress Shield Installment Procedure

P/N: 111032

COLINE
14140 NE 200th St.
Woodinville, WA. 98072
(425) 398-8282



Step 1. Turn off machine and un-plug.



Step 2. Rotate clamp to the open position.



Step 3. Lift arm and use clamp to hold in place.



Step 4. Remove 2 screws and wiper.



Step 5. An unobstructive view of the shield to be removed.



Step 6. Peel off the old shield.



Step 7. Peel off tape.



Step 8. Clean area with Alcohol for the placement of the new tape pieces.



Step 9. Cut new tape to size and adhere.



Step 10. Peel off clear protective film from both pieces of tape.



Step 11. Using the notch on the shield as a guide, place the shield as shown and press down onto the tape.



Step 12. Shows how the shield should appear.



Step 13. Re-install the wiper using the 2 screws. Do NOT over tighten. (Over tightening the screws may damage the wiper)



Step 14. Finished.