

CPII Wiper Install Procedure

P/N: 110950

COLINE
14140 NE 200th St.
Woodinville, WA. 98072
(425) 398-8282



Step 1. Turn off machine and un-plug.



Step 2. Open clamp



Step 3. Lift arm and use the clamp (Arrow) to hold in place.



Step 4. Unscrew (2 screws) wiper and remove.



Step 5. Ready to receive the new wiper.



Step 6. Place the 2 screws in the wiper before you screw it to the arm. This will make it easier to attach. The wiper must be orientated as above. Foam should be facing the arm as shown



Step 7. Install the new wiper. Do NOT over tighten the screws, it could cause the wiper to fracture if tightened too much.



Step 8. Photo shows how the wiper (arrow) should look when affixed properly. FINISHED