

1. ";;" Select-code.
 - for P600 this causes an endplate seek and selects DMPL language
 - for 2200 this just selects DMPL language
2. ";;I" Mode 2 select
3. "@" Deselect-code
 - for P600 this just exits the DMPL language
 - for 2200 this causes an endplate seek and exits DMPL language
4. "A" Plot Absolute command
5. "D" Pen Down
6. "F" Frame advance
7. "H" Home
8. "L" Set Line-type
9. "M" Marker plot
10. "O" Set Origin
11. "P" Select Pen
 - We don't have a pen stall for automatic pen changes but all other effects of this command are supported).
12. "Q" Query
13. "R" Plot Relative command
14. "S" Simple text
15. "T" Plotter Test
16. "U" Pen Up
17. "V" Set Velocity
18. "W" Set Window

19. "Z" Plotter reset
20. "p" Incremental move, + y
21. "q" Incremental move, + x, + y
22. "r" Incremental move, + x
23. "s" Incremental move, + x, - y
24. "t" Incremental move, - y
25. "u" Incremental move, - x, - y
26. "v" Incremental move, - x
27. "w" Incremental move, - x, + y
28. "y" Pen up
29. "z" Pen down
30. "EC" Coordinate Addressing
31. "CA" Circle Arc plot command
32. "CC" Circle Circle plot command
33. "CE" Circle Ellipse command
34. "CG" General Curve plot command
35. Only partially implemented, curves will come out rough.
36. "EB" Prompt Enable command
37. "ER" Report output command
38. "ET" End of Text character definition command

CURRENTLY NOT SUPPORTED

"X" Pass Through Port Enable

"ED" Digitize

"EF" Large Chart

"EH" Small Chart

"EL" Plotter Pause

"EM" Keyboard mask

"EU" UART setup.