



14140 NE 200th ST. • Woodinville, WA. 98072 • PH: (425) 398-8282 • FX: (425) 398-8383

Procedure: FlexJet bay PCB adjustment

Symptom: Print head will stop printing or get lighter.


Tools Required:

Flat-Head screwdriver

Bay Identification


New Bays

Old Bays



Adjustment

WARNING: Be extremely carefull when performing this procedure. Use a small head screwdriver and make every effort to avoid touching the metal pins on the PCB.



Push down on the shelf with a flat head screwdriver to seat the PCB.