


Installing a pinch wheel assembly on a Studio 8 / Super 88

IOLINE™

14140 NE 200th St.
Woodinville, WA. 98072
(425) 398-8282


1. Place the pinch wheel assembly next to the square shaft.




2. Push down on the lever on the top of the pinch wheel assembly until the lever goes up over the square shaft.



3. Gently push the pinch wheel assembly under the square shaft with the lever raised.



4. Release the lever on the pinch wheel assembly until it's locked onto the square shaft.



Note

You may have to push the square shaft up a little to slide the pinch wheel assembly under the square shaft.



Note

If the pinch wheel assembly doesn't click onto the square shaft, pull up on the back side of the pinch wheel assembly until it clicks onto the square shaft.